

## Excitation-Wavelength Dependent and Time-Resolved Photoluminescence Studies of Europium Doped GaN Grown by Interrupted Growth Epitaxy (IGE)

Ei Ei Nyein<sup>1</sup>, Uwe Hömmerich<sup>1,\*</sup>, Chanaka Munasinghe<sup>2</sup>, Andrew J. Steckl<sup>2</sup>, and John M. Zavada<sup>3</sup>

<sup>1</sup>Department of Physics, Hampton University, Hampton, VA 23668

<sup>2</sup>Department of Electrical and Computer Engineering, University of Cincinnati, OH 45221

<sup>3</sup>U.S. Army Research Office, Research Triangle Park, NC 27709

\*E-mail: uwe.hommerich@hamptonu.edu

### ABSTRACT

The emission properties of Eu doped GaN thin films prepared by interrupted growth epitaxy (IGE) were investigated through excitation-wavelength dependent and time-resolved photoluminescence (PL) studies. Under above-gap excitation (333-363 nm) large differences were observed in the Eu<sup>3+</sup> PL intensity and spectral features as a function of Ga shutter cycling time. The overall strongest red Eu<sup>3+</sup> PL intensity was obtained from a sample grown with a Ga-shutter cycling time of 20 minutes. The main Eu<sup>3+</sup> emission line originating from <sup>5</sup>D<sub>0</sub> → <sup>7</sup>F<sub>2</sub> transition was composed of two peaks located at 620 nm and 622 nm, which varied in relative intensity depending on the growth conditions. The room-temperature emission lifetimes of the samples were non-exponential and varied from ~50 μs to ~200 μs (1/e lifetimes). Under resonant excitation at 471 nm (<sup>7</sup>F<sub>0</sub> → <sup>5</sup>D<sub>2</sub>) all samples exhibited nearly identical PL spectra independent of Ga shutter cycling time. Moreover, the Eu<sup>3+</sup> PL intensities and lifetimes varied significantly less compared to above-gap excitation. The excitation wavelengths dependent PL results indicate the existence of different Eu<sup>3+</sup> centers in GaN: Eu, which can be controlled by the Ga shutter cycling time.

### INTRODUCTION

Rare-earth (RE) doped III-V compound semiconductors have received significant attention due to their applications in light emitting devices and for their unique optical and electrical characteristics [1,2]. In recent years, RE ions have been introduced into GaN for optoelectronic devices operating in the ultraviolet (UV), visible, and infrared (IR) spectral region [1,2]. Eu<sup>3+</sup> doping of GaN has been of particular interest because of its efficient red emission at ~622 nm used in electroluminescence (EL) devices [2]. In addition, Eu<sup>3+</sup> exhibits a relatively simple energy diagram, which makes Eu<sup>3+</sup> an excellent spectroscopic probe [3-5]. The ground state level <sup>7</sup>F<sub>0</sub> and the lowest emitting level <sup>5</sup>D<sub>0</sub> of Eu<sup>3+</sup> are non-degenerate. Therefore, the optical transition <sup>5</sup>D<sub>0</sub> → <sup>7</sup>F<sub>0</sub> can provide important information on different Eu<sup>3+</sup> centers in the GaN lattice.

The main aim of this research is to develop compact, efficient, and bright EL devices based on RE doped GaN thin films. To achieve this goal, the materials need to be optimized for several growth parameters: e.g. RE concentration, growth temperature, and III/V ratio. In this work, a set of GaN:Eu samples was prepared by a new growth technique called “Interrupted Growth Epitaxy” (IGE) [6]. During IGE the group III (Ga) shutter is closed for a certain time interval, which allows the GaN: Eu film to compensate for any nitrogen deficiency. Improvements in the GaN: Eu EL device performance by more than an order of magnitude were

Report Documentation Page			Form Approved OMB No. 0704-0188		
Public reporting burden for the collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to a penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number.					
1. REPORT DATE <b>2005</b>		2. REPORT TYPE		3. DATES COVERED <b>00-00-2005 to 00-00-2005</b>	
4. TITLE AND SUBTITLE <b>Excitation-Wavelength Dependent and Time-Resolved Photoluminescence Studies of Europium Doped GaN Grown by Interrupted Growth Epitaxy (IGE)</b>				5a. CONTRACT NUMBER	
				5b. GRANT NUMBER	
				5c. PROGRAM ELEMENT NUMBER	
6. AUTHOR(S)				5d. PROJECT NUMBER	
				5e. TASK NUMBER	
				5f. WORK UNIT NUMBER	
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) <b>University of Cincinnati, Nanoelectronics Laboratory, Cincinnati, OH, 45221-0030</b>				8. PERFORMING ORGANIZATION REPORT NUMBER	
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES)				10. SPONSOR/MONITOR'S ACRONYM(S)	
				11. SPONSOR/MONITOR'S REPORT NUMBER(S)	
12. DISTRIBUTION/AVAILABILITY STATEMENT <b>Approved for public release; distribution unlimited</b>					
13. SUPPLEMENTARY NOTES					
14. ABSTRACT					
15. SUBJECT TERMS					
16. SECURITY CLASSIFICATION OF:			17. LIMITATION OF ABSTRACT	18. NUMBER OF PAGES <b>6</b>	19a. NAME OF RESPONSIBLE PERSON
a. REPORT <b>unclassified</b>	b. ABSTRACT <b>unclassified</b>	c. THIS PAGE <b>unclassified</b>			

observed from GaN: Eu films grown by IGE compared to conventional MBE [6]. Initial studies of the photoluminescence (PL) properties of these samples are presented in this paper.

## EXPERIMENTAL PROCEDURES

IGE was recently developed at the University of Cincinnati in order to determine the optimum group V/III growth ratio for GaN: Eu. Closing the Ga shutter for a certain time interval allows the GaN:Eu film to compensate for any nitrogen deficiency. A set of Eu doped GaN films with group III (Ga) shutter open times of 5, 10, 15, 20, 30, and 60 min were grown using IGE technique on Si substrates. A full growth run of Eu doped GaN covered a time period of 60 minutes. For the main growth, the substrate temperature was ramped to 650 °C and the Ga cell temperature was 900 °C. The Eu cell temperature was 440 °C, resulting in an estimated Eu concentration of ~0.1 at. % [6].


PL measurements were performed using the UV argon laser line (333.6-363.8) nm for above-gap excitation. Resonant pumping into the  ${}^7F_0 \rightarrow {}^5D_2$   $\text{Eu}^{3+}$  transition at ~ 471 nm was obtained using the output of a Nd:YAG pumped Optical Parametric Oscillator (OPO) system. For temperature-dependent PL measurements, the sample temperature was controlled between 15 K and 300 K using a two-stage closed-cycle helium refrigerator. The visible luminescence was analyzed by a 0.5 or 1-m monochromator and detected with a thermo-electric cooled photomultiplier tube (PMT). PL lifetime data were taken with the third harmonic output of a pulsed Nd:YAG laser (355-nm) for above-gap excitation and the OPO system operating at ~ 471 nm for resonant excitation. The luminescence signal was processed using either a lock-in amplifier or a boxcar averager and PL decay curves were recorded using a digitizing oscilloscope.

## RESULTS AND DISCUSSION

### Above-gap emission spectra and PL decay


Figure 1 shows an overview of the room-temperature PL spectra of Eu doped GaN for various Ga shutter cycling times. The PL was excited using an UV argon laser (333.6-363.8 nm), which corresponds to above-gap pumping. The characteristic  $\text{Eu}^{3+}$  red emission at ~ 622 nm attributed to the intra-4f  ${}^5D_0 \rightarrow {}^7F_2$  transition was observed in all samples accompanied by other  $\text{Eu}^{3+}$  lines at ~ 601 nm ( ${}^5D_0 \rightarrow {}^7F_1$ ) and ~ 663 nm ( ${}^5D_0 \rightarrow {}^7F_3$ ). The strongest red emission was observed from GaN:Eu with a shutter cycling time of 20 min as illustrated in Fig. 1 (a). The integrated PL intensity as a function of Ga shutter cycling time is also depicted in Fig. 1 (b).

It can be noticed from Fig. 1, that the main red emission line consisted of two peaks at ~ 620 nm and ~ 622 nm. The intensity ratio of these two PL lines changed as a function of Ga shutter cycling time. The GaN:Eu sample with the strongest  $\text{Eu}^{3+}$  PL intensity exhibited mainly emission from the 620 nm PL line. The observation of two strong  ${}^5D_0 \rightarrow {}^7F_2$  PL lines suggests the existence of two dominant  $\text{Eu}^{3+}$  sites (labeled in the following as site 1 and site 2). It is also interesting to note that the PL line at ~ 633 nm was unusually pronounced in some GaN:Eu samples, and was correlated with the 620 nm PL line intensity. The weak emission lines at 583, 586, and 589 nm are most probable due to  ${}^5D_0 \rightarrow {}^7F_0$  transitions further indicating the existence of different  $\text{Eu}^{3+}$  centers in GaN:Eu samples grown by IGE technique [6].



**Figure 1.** (a) Room temperature PL spectra of GaN:Eu films under above-gap excitation. The group III shutter open times are also indicated in the graph. (b) Integrated PL intensity of GaN:Eu films as a function of Ga/Eu shutter cycling time.


The room temperature PL decay transients under above-gap excitation are shown in Fig. 2. It can be noted that the PL lifetimes varied significantly between the samples. The PL decay transient of the strongest emitting sample (20 min) showed a  $1/e$  lifetime value of only  $\sim 54 \mu\text{s}$ .



**Figure 2.** PL decay transients of GaN:Eu films under above-gap excitation (355 nm) at 300 K.

The PL decays of GaN:Eu films with Ga shutter cycling times of 10 and 15 min were nearly exponential with  $1/e$  lifetime values of  $\sim 208 \mu\text{s}$ . The 5, 30, and 60 min samples, which have both  $\text{Eu}^{3+}$  sites, showed PL lifetimes between  $\sim 75 \mu\text{s}$  and  $\sim 120 \mu\text{s}$ . The PL decay measurements indicate that  $\text{Eu}^{3+}$  site 1 (PL peak:  $\sim 620 \text{ nm}$ ) has a “short” lifetime of  $\sim 54 \mu\text{s}$  and  $\text{Eu}^{3+}$  site 2 (PL peak:  $\sim 622 \text{ nm}$ ) possesses a “long” lifetime of  $\sim 208 \mu\text{s}$ .

Figure 3 depicts the temperature dependent PL lifetimes for samples with Ga shutter cycling times of 20 and 10 min. The PL lifetime of the 20 min sample exhibited a large change in lifetime between 15 K and 300 K, as shown in Fig. 3 (a). The  $1/e$  PL lifetime values at 15 K and 300 K were  $\sim 158 \mu\text{s}$  and  $\sim 54 \mu\text{s}$ , respectively, which shows a  $\sim 66 \%$  decrease relative to its low temperature value. On the other hand, the PL lifetimes were nearly temperature independent for the GaN:Eu sample with a Ga shutter time of 10 min. For this sample the lifetime decreased by only  $\sim 17 \%$  relative to its low temperature value [see Fig. 3 (b)]. The large difference in the decay time behavior provides further support for the existence of different  $\text{Eu}^{3+}$  sites in these samples.




**Figure 3.** Temperature dependent PL decay transients for the samples with Ga shutter time (a) 20 min and (b) 10 min under above-gap excitation. The  $1/e$  lifetime values are also indicated in the graph.

### **Below-gap emission Spectra and PL decay**

To gain more insight in the  $\text{Eu}^{3+}$  PL properties of GaN:Eu prepared by IGE, PL spectra were recorded under resonant intra-4f  $\text{Eu}^{3+}$  excitation using the 471nm output of an OPO system [Fig. 4 (a)]. Nearly identical  $\text{Eu}^{3+}$  PL spectra with the  $^5\text{D}_0 \rightarrow ^7\text{F}_2$  emission line at  $\sim 622 \text{ nm}$  were observed for all samples. This observation suggests that  $\text{Eu}^{3+}$  site 2 is dominant under resonant pumping. The normalized PL spectra under above-gap excitation are shown in Fig. 4 (b) for comparison.

The differences in PL spectra under above-gap and resonant-excitation further indicate that different  $\text{Eu}^{3+}$  centers were formed in GaN during the IGE growth process. Compared to above-gap excitation, resonant  $\text{Eu}^{3+}$  excitation preferentially excites only one  $\text{Eu}^{3+}$  site (site 2).


The PL decay monitored at  $\sim 622$  nm under resonant-excitation showed that the transients are nearly exponential with variations in  $1/e$  lifetimes ranging from  $\sim 100$ -215  $\mu$ s.



**Figure 4.** Normalized PL spectra of GaN: Eu under (a) resonant and (b) above-gap excitation. The group III shutter open times during IGE growth are also indicated in the graph.

### PL excitation measurements

We recently studied the incorporation of  $\text{Eu}^{3+}$  ions in GaN: Eu films grown by conventional solid-source MBE (SSMBE) technique and identified at least five  $\text{Eu}^{3+}$  centers [5]. Initial PL excitation (PLE) studies at room-temperature were performed on GaN: Eu samples grown by IGE technique as shown in Fig. 5.



**Figure 5.** Room temperature PLE spectra of GaN:Eu films with various Ga shutter cycling time.

The  $\text{Eu}^{3+}$  luminescence was monitored at  $\sim 622$  nm and the excitation wavelength was scanned in the spectral region of the  ${}^7\text{F}_0 \rightarrow {}^5\text{D}_0$  transition between 565 and 600 nm. Interestingly, the observed PLE spectra were similar to the results obtained from GaN:Eu grown by SSMBE [5]. Three main PLE peaks were observed at  $\sim 571$ , 585, and 588.5 nm from all samples. For some samples the  $\sim 571$  nm lines exhibited a splitting into two lines. The PLE line at 591 nm does not originate from the  ${}^7\text{F}_0$  ground state, as previously reported [5]. The obtained PLE spectra further demonstrate the existence of different  $\text{Eu}^{3+}$  centers in the GaN:Eu samples prepared by IGE growth. An attempt was made to selectively excite the different  $\text{Eu}^{3+}$  centers using the tunable laser output from an OPO system. However, due to a poor signal to noise ratio, no spectral differences were observed. Further site-selective PL spectroscopy is needed to elucidate the incorporation of different  $\text{Eu}^{3+}$  sites in GaN sample grown by IGE technique.

## SUMMARY

Spectroscopic results on the emission properties were presented on a set of GaN:Eu films grown by interrupted growth epitaxy (IGE). The strongest  $\text{Eu}^{3+}$  red emission under above-gap excitation was observed for a sample with a 20 min Ga cycling time. Two  $\text{Eu}^{3+}$  sites with the  ${}^5\text{D}_0 \rightarrow {}^7\text{F}_2$  PL peaks located at 620 nm (site 1) and 622 nm (site 2) were dominant in the above-gap PL spectra. It was found that  $\text{Eu}^{3+}$  site 1 exhibited a “short” lifetime ( $\sim 54$   $\mu\text{s}$ ) and  $\text{Eu}^{3+}$  site 2 had a “long” lifetime ( $\sim 208$   $\mu\text{s}$ ). Contrary to above-gap excitation, resonant  $\text{Eu}^{3+}$  excitation selectively excited only one  $\text{Eu}^{3+}$  center (site 2). PLE measurement in the  ${}^7\text{F}_0 \rightarrow {}^5\text{D}_0$  spectral region provided further supported for the different  $\text{Eu}^{3+}$  centers in these samples. Additional high-resolution PL and site-selective PL studies are required for these samples to obtain a better understanding of the incorporation of  $\text{Eu}^{3+}$  ions into GaN. Also, efforts to relate the  $\text{Eu}^{3+}$  PL properties to the crystalline quality of GaN: Eu samples grown by IGE are still in progress.

## ACKNOWLEDGEMENTS

The authors from Hampton University would like to acknowledge financial support by ARO grant DAAD19-02-1-0316. The work at University of Cincinnati was supported by ARO grant DAAD19-03-1-0101.

## REFERENCES

1. *Rare Earth Doped Materials for Photonics*, Proceedings of E-MRS Symposium Spring 2003, (P.Ruterana, Editor.), Mater. Sci. Eng. **B105**, Elsevier (2003).
2. A. J. Steckl, J. C. Heikenfeld, D. S. Lee, M. J. Garter, C. C. Baker, Y. Wang, R. Jones, IEEE J. Sel. Top. Quant. Electronics **8**, 749 (2002).
3. T. Monteiro, C. Boemare, M. J. Soares, R. A. Sa Ferreira, L. D. Carlos, K. Lorenz, R. Vianden, E. Alves, *Physica B* **308-310**, 22-25 (2001).
4. Ei Ei Nyein, U. Hömmerich, J. Heikenfeld, D. S. Lee, A. J. Steckl, and J. M. Zavada, *Appl. Phys. Lett.* **82**, 1655-1657 (2003).
5. U. Hömmerich, E. E. Nyein, D. S. Lee, J. Heikenfeld, A. J. Steckl, and J. M. Zavada, *Mater. Sci. & Eng.* **B105**, 91-96 (2003).
6. C. Munasinghe and A. J. Steckl, *Proceedings of the International Electroluminescence Conference*, Toronto, Canada, September 2004, pp.341-343.